

**iD Inspiration High traffic 70**  
**iD Inspiration 55**  
**iD Inspiration 30**  
**iD Inspiration Click High Traffic 70**  
**iD Inspiration Click Solid 55**  
**iD Inspiration Click Solid 30**  
**LUXURY VINYL TILES WITH TEKTANIUM™**

**Cleaning & maintenance instructions**

2021

**GENERAL ADVICE**

- Clean the floorcovering regularly as this is more cost effective and hygienic than occasional heavy duty cleaning.
- Always follow dosage instructions carefully.
- Wipe up any grease and spilt oil immediately, as it may damage the surface.
- Resilient floors are damaged by solvents.
- Black rubber wheels and rubber feet can discolour the floorcovering. All chair and table legs should have good quality feet. Felt feet are not recommended in commercial interiors. Hard plastic is preferred.
- Remember that light colours need more frequent cleaning.



**TEKTANIUM™**

**Excellent resistance and easy cleaning**

Our new TEKTANIUM™ PU coating uses a proprietary polymer system - forming a naturally clear, verifiably stronger layer of protection that delivers unequalled resistance to scratches, abrasions, wear and stains. Moreover, it offers a pure ultra matt finish, which is consistently visible from all angles.

**Initial site cleaning**

Always protect the floor with thick paper or hard board during the construction period. After the installation, always clean the new floor: vacuum, sweep or damp mop the area to remove building dust and loose dirt. A combined scrubber/dryer with cylindrical brushes is very effective to clean large areas. Use detergent with a low pH (3-5).

**PREVENTIVE CARE**



**Entrance matting**

About 80% of surface soiling that has to be cleaned off is brought from outside. And 90% of that soiling can be avoided by an effective and correctly dimensioned entrance mat. The less dirt that comes in through the entrance, the lower the maintenance requirements.

**DAILY AND REGULAR CLEANING**



**Dry mopping**

Remove dust and dirt with dry mop.

OR



**Vacuum cleaning**

To remove dust and loose dirt. Recommended for large areas and initial site cleaning.



**Damp mopping**

Use a mop dampened with water or detergent solution. It is essential that water does not stay on the floor or leave a film. The floor should be virtually dry after 15-20 seconds.

OR



**Combined machine with brush**

Industrial machine-cleaning (large areas). Use diluted neutral detergent. Adjustable speed 300-500rpm. Use nylon brush not white/beige pad!



**Manual brush**

Brush (with medium brushes).

OR



**Rotowash with brushes**

Spray diluted detergent and clean with water or water+detergent.



**Spot and stain removal**

Treat stains immediately. Hand spot using a white/red nylon pad with neutral detergent (solvents should not be used). Work from the outside of the mark towards its centre. Rinse and wipe afterwards with clean water.

**PERIODICAL CLEANING**



**Light soiling: Spray Cleaning**

Mix water and neutral detergent in the container tank. Suitable speed 300-500rpm. Red pad is recommended.



**Heavy soiling: Rotowash**

Clean with the cylindrical scrubbing machine (spray detergent diluted with water through the machine).

**If needed:**



**Dry buffing**

When necessary, dry buff to recover gloss. White-beige pad. Suitable speed is 500-1000rpm.

*If any doubts or clarifications should be needed, please contact your local Tarkett representative for further information.*

